


# BASEUL UHF Base Assembly



## INSTRUCTIONS

Strip coax as illustrated then feed through the center of the Boltul screw tightly up the bolt center then solder the top of the bolt.

